


**Safety First!**

Use only Genuine Dualco Parts.

Contact Dualco for repair, or
rebuilding procedures.**General**

Key	Description	Part No.
1	Foot Pump Assembly	11631
2	Elbow	11431
3	Nipple 4" S.S.	11291
4	Gauge, Cover	11835
5	Elbow (2 Required)	11431
6	Cradle Assembly • See Page 2 •	12020
7	Pump Fasteners Set includes: ★	12030
	★ Cap Screw (4 Required)	12013
	★ Washer (8 Required)	12016
	★ Nut (4 Required)	12014


General (continued)

Key	Description	Part No.
8	Piston Return Tube / Cap Wrench	12035
9	Clip Assembly includes: ※	12040
	※ Handle Clip (2 Required)	11148
	※ Pan Head Screw (2 Required)	12038
	※ Lock Washer (2 Required)	12039
10	Frame	11632
11	Barrel Assembly • See Page 3 •	12015
12	Pedal Lock Assembly	11661

Notes:See Page 3 for Barrel and Hose Assembly
Schematics and parts lists.Hose Assembly, model 12021, is an integral
component of the Foot/Hydraulic Injection
Gun - Model 11725.**DUALCO**[™]

All Rights Reserved. © Copyright 2018 DUALCO Inc.

DUALCO • 8404 Braniff, Houston, Texas 77061
713-644-1164 • FAX 713-644-7761
www.dualco-inc.com
E-Mail: dualco@dualco-inc.comManufacturers of
Professional Lubrication
Equipment since 1960
Made in USA

Cradle Assembly
Part 12020


Cradle Assembly • 12020


Key	Description	Part No.
15	Hex Head Cap Screw 7/16-14 x 3.5" S.S. (4 Required)	12011
16	Cradle Top Plate (2 Required)	11344
17	Barrel Cradle (Top and Bottom Identical) (4 Required)	11343
18	Washer Flat-1.0"OD x 0.5"ID S.S. (4 Required)	11789
19	Nylock Nut 7/16-14 S.S. (4 Required)	12012

Notes:

Barrel Assembly (#12015) and Frame (#11632) are separate parts and not part of the Cradle Assembly.

Part numbers 12015 and 11632 as shown on the Cradle Assembly schematic are for reference.



Barrel Assembly
Part 12015

General

Key	Description	Part No.
1	Grease Barrel Cap	10813
2	"O" Ring (2 Required)	10811
3	Grease Barrel	11284
4	Body	12001
5	Protective Plug (for Grease Barrel Cap)	10568


Piston Assembly 10810

Key	Description	Part No.
6	Piston	10815
7	"O" Ring (Piston) (2 Required)	◆ 10818
8	Washer Nut (2 Required)	10819
9	Leather Cup (2 Required)	◆ 10821
10	Gasket	◆ 10817
11	Cap Screw	10816

Repair & Maintenance Kits

Description	Part No.
Repair Kit, Minor includes: ◆	12008
◆ Piston Assembly	10810
◆ Hydraulic Hose (Pump to Cylinder)	11318
Piston Seal Kit includes: ◆	11598

The Piston Assembly (part 10810) has an integral bleeder cap screw with a copper gasket. The bleeder assembly facilitates easy bleeding to assure there's no air entrapment.

Hose Assembly
Part 12021

Hose Assembly • 12021

Key	Description	Part No.
12	GBH Coupler	10850
13	Shut Off / Relief valve	10990
14	Straight Swivel	11337
15	Hose • 72" • 10,000 psi	7231776
16	"Z" Swivel (Compact)	10744L

 **Caution!**

Pressure ratings must not be exceeded. All hoses, fittings, and connections must be checked, tightened, and securely fastened on a regular basis. Weak, worn or damaged hoses can rupture - causing human injury and property damage. Always use damage-free components and discard a hose after 3 years of use or before, if any signs of damage have occurred.

Most DUALCO products are designed for industry use, not for home use.