

Designation of digital Inputs/Outputs

Printing

Each of the digital inputs and outputs may be associated with any physical input or output of the transmitter.

Digital outputs


no.	Function
1	Weighing conveyor running
2	Upstream conveyor running
3	Automatic start
4	Sliding average alarm
5	General alarm
6	Ejector 1
7	Ejector 2
8	Ejector 3
9	Ejector 4
10	Ejector 5
11	Ejector 6
12	Ejector 7
14	Start Conveyor speed controller
15	Start upstream Conveyor speed controller
16	Start downstream conveyor speed controller
35	Weight in zone 1
36	Weight in zone 2
37	Weight in zone 3
38	Weight in zone 4
39	Weight in zone 5
40	Weight in zone 6
41	Weight in zone 7
42	Weight in zone 8

Digital Inputs

no.	Function
20	Start weighing detector
21	Throughput management detector
22	Start sorter
23	Saturation of downstream belt
25	Start weighing conveyor
26	Speed detector
27	Request product ejection
31	Restart sorter belt

Printing of each weighing and/or end of batch.

Output to printer or USB memory stick (virtual printer).



Weighing screens

DCKW mode: Dynamic weighing

•		•	
	1F1	XIII(0,5)	(6)
√ V3.1.0 V0.0.BR		220V/50Hz	$\overline{\mathbf{v}}$
T = -Max	1	v=0.75m/s	шn
Max 3kg			нк
── Min 20e		ŀ	
+T + e=d=0.001kg			
⊢	~ /	NACH	
<u>-</u> ♠	J.l)02kg	R/G
[×]	•	· · · ·	0.0
⋥	_	ſ	Щ
\∆lpsp : 503	2	00000036	니

CKW mode: Static weighing

2 CKWMANU V3.0.0 V2.0.0	Υ(a) 60/mp 0.26m/s	<u>@</u>
+0+ T=-Max1	230V 50Hz	HR
Max1 3000 g	Max2 6000 g W2 Min2 20e	
• T + e1=d1=1 g	e2=d2=2 g	ָעַ
→ 0 ←	ፈ በበበ ~	<u> </u>
r∰ Net	3000 g	B/G
DSD : 65535	7 0000080	٥

Data storage (DSD) :

Max. number of records 48,000.

Record contains: DSD no., gross weight, tare weight, net weight, predetermined tare, type of weight printed, type of weight transmitted by protocol, units, identification no.

Your weighing specialist

Illustrations are not contractual. Precia-Molen reserves the right to modify at any time, without prior notice, the information contained in this leaflet.

Offices and Factory

Offices and Factory
P.O. Box 106 - F 07000 Privas - France
Tel. 33 (0) 475 664 600
Fax 33 (0) 475 658 330
E-MAIL webmaster@preciamolen.com

RCS: 386 620 165 RCS Aubenas









06/2008 04-32-70-1 F7

7 -

Application

The I 400 CKW software fulfils most industry requirements for discontinuous dynamic weighing.

- In motion weighing
- Checking production tolerance
- Weight classification
- Checking order compliance
- Checking prepacked goods
- etc

Weighings can be obtained either dynamically or statically.




Functions

- Management of 1 to 8 weight classes that can be associated with 7 ejection systems.
- Determination of threshold values in 6 modes:
- legislation of prepacked goods
- relative,
- relative sliding,
- absolute.
- percentage,
- · sliding percentage.
- Batch identification with two associated reference files and one free text field.
- Control of the weighing conveyor and an upstream spacing conveyor and downstream ejector conveyor (options).
- Batch statistics: histograms by class, average, standard deviation, etc...
- Results can be printed.
- Record of weighings which can be transferred onto a USB memory stick.
- Full control of the process by averages via a MODBUS serial link or CAN Open fieldbus, Profibus DP, Device Net, TCP/MODBUS.
- Several operating modes:
- acquisition of weight in motion (catch weigher),
- stop product for addition or removal,
- sorter/calibrator with ejection, etc.

7

Operator interface



- 1. Main application display:
 - · Display package weight,
 - Statistics (number of packages weighed, average, standard deviation),
 - Conveyor speed; weighing frequency,
 - Status of the machine (stopped, running, fault, etc.),
 - Alarm,
 - Fault number.
- Conveyor stop
- Conveyor start,
- F6: access batch screen.
- **5.** F7: access statistics screen.
- 6. F8: access file screen.

Function keys F1 to F10 and SF1 to SF4 are structured at several levels. They can have different functions depending on the context.



Configuration


The various operating parameters of the I400 system, which are configurable are organised in 7 files and four levels of operation, password protected:

- Installer
 - Metrological adjustment and Input/Output configuration.
- Supervisor:
 - Setting up the peripherals.
- Operator:
 - Definition of dosage set points and access to results.
- User:
- · Limited rights to start batches.

This segmenting of parameters makes the I 400 system modular and easily integrated into the majority of industrial processes. The functioning of the application is therefore more secure as it denies access to unauthorised operators.

Technical data

Batch identification



- 1. Set up/start a batch by entering the various batch data:
 - Batch no. (12 char. alphanum.),
 - Item code.
 - · class code.
 - reference 1 (code 12 char. alpha., name 20 char. alpha.),
 - reference 2 (code 12 char. alpha., name 20 char. alpha.),
 - free info (12 char. alphanum.),
- 2. Stop current batch.
- 3. Print batch (if printer option fitted).
- **4.** Weighing conveyor status (stop, or current).
- 5. Message display (fault, alarm, etc.).
- **6.** Return to "Operation monitoring" screen
- 7. Access "Statistics and distribution" screen.



User data

File characteristics

Capacity	Code	Name	Access level
100	13c. alpha.	20c. alpha.	Operator
50	13c. alpha.	20c. alpha.	Supervisor
7	1 to 7	-	Supervisor
100	12c. alpha.	20c. alpha.	Operator
100	12c. alpha.	20c. alpha.	Operator
400	-	-	User
	100 50 7 100 100	100 13c. alpha. 50 13c. alpha. 7 1 to 7 100 12c. alpha. 100 12c. alpha.	100 13c. alpha. 20c. alpha. 50 13c. alpha. 20c. alpha. 7 1 to 7 - 100 12c. alpha. 20c. alpha. 100 12c. alpha. 20c. alpha.

Ejector file

Parameters	Format – value	Comment
Ejector distance	in mm	Between the weighing detector and the ejection axis
Ejector cmd time	in ms	Definition of reaction time

Items file

Parameters	Format – value	Comment
Code	13 c. Alpha.	-
Label	20 c. Alpha.	-
Nominal weight	in kg	-
Tare	in kg	-
Price	in €/kg (UK market is £ possible?)	(0: no price calculation)
Class record code	050	(0: no link with the class file)

Class file

This file is used to manage up to 8 weight zones by class with the ability to choose different ways of calculating the thresholds

- Prepacked: automatically calculated according to the nominal weight and legislation for prepacked goods.
- Relative: with respect to the nominal weight (signed values).
- Relative sliding: according to the average sliding weight.
- Absolute: direct comparison with the net weight.
- Percentage: with respect to the nominal weight (signed values in %).
- Sliding percentage: with respect to the sliding average (values in signed %).


For each zone, choice of method:

- None.
- Ejector from 1 to 7 (selective sorting),
- Stop ejection,
- Stop adjustment, (to re-adjust the weight of the package).

Result file

Parameter	Format	
Batch code	12c. alpha.	
Item code	13c. alpha.	
Date batch start	dd/mm/yy	
Time batch start	hh/mm/ss	
Date batch end	dd/mm/yy	
Time batch end	hh/mm/ss	
Machine no.	2 c. num	
Class code	2 c. num	
Reference code 1	12c. alpha.	
Reference code 2	12c. alpha.	
Items weighed counter	6 c. num	
Zone 1 items counter	6 c. num	
Total weight zone 1	7 c. num. including decimal point	
Items and total weight counter zone, same for zones 2 to 8		
Average weight of batch	5 (weight)	
Standard deviation of batch	5 (weight)	
Minimum package weight for batch	5 (weight)	
Maximum package weight for batch	5 (weight)	
Unit	2 c. alpha (g or kg)	

Statistics



Distribution screen:

- · Recall threshold.
- · Histogram of weighings,
- · Counters by class.

STATISTIQUES DU LOT(kg)			
ZONES	TOTAUX		
ZONE 1	50.465	MOY: 2.04	
ZONE 2	164 .543	S : 0.24	*
ZONE 3	0.000	MIN: 1.12	= ₊
ZONE 4	217 .258	MAX: 3.00	-1
ZONE 5	109 .510		
ZONE 6	99 .404	NB STAT: 377	
ZONE 7	50.793	<u>NB TOT</u> : 379	
ZONE 8	77 .486	NB DEF : 0	

Batch Statistics screen:

- Totals by zone,
- · Batch average
- Standard deviation,
- Batch minimum package weight,
- · Batch maximum package weight,
- Total number of weighings taken into account for the statistics,
- Total number of packages weighed.

