


Fiber Type Sensor Head

Sensor Head

Sensor head for HMD/CMD.


Fiber type and non-air dust-purge hood.

Sensor head such as withstanding bad environment is also lined-up.



FHM-201-8WA
(Wide directivity for HMD)

FHM-203
(Narrow directivity for HMD)



FHM-111-4

FHM-201


FHM-211-1

FHM-311


(Standard type for HMD /CMD)

Spread of beam


FHM-201 Spread : $\varphi 0\text{mm} \times \text{distance}$




FHM-111-4 Spread : $\varphi 20\text{mm} \times \text{distance}$




FHM-211-1 Spread : $\varphi 20\text{mm} \times \text{distance}$ (but $\varphi 0\text{mm}$ up to 2m)




FHM-201-8WA Spread : $40 \times 500 \times \text{distance}$



FHM-311 Spread : $\varphi 13.3\text{mm} \times \text{distance}$ (but $\varphi 56\text{mm}$ up to 4.2m)




FHM-203 Spread : $10 \times 60 \times \text{distance}$




External dimensions


FHM-201




FHM-111-4




FHM-211-1



FHM-201-8WA



FHM-311



FHM-203

